








## BOOT SPOILER INSTALLATION GUIDE

Please inspect the boot spoiler prior to installation and report any issues.

Do a test fit on the vehicle before fitting the 3M Tape to make sure the fit is correct and to find the perfect location for the spoiler. It's very important to clean the boot surface with alcohol rub or mentholated spirits to remove any oil, wax and dirt from the surface.

**Attach/ stick the supplied 3M tape to the back / underside of the boot spoiler, using all the tape to cover all areas of contact with the car boot. Once tape is fitted please follow the spoiler installation steps below:**

				
<b>STEP 1:</b> Clean boot / trunk lid with alcohol rub or mentholated spirits. Making sure there is no dust, wax or dirt on the surface.	<b>STEP 2:</b> Peel of the pre-fixed backing tape a bit at one side as shown in picture above.	<b>STEP 3:</b> Stick the spoiler from one side of the boot to the other; follow the curvature of the boot / trunk lid to the other side.	<b>STEP 4:</b> Slowly peel off the tape, pressing down on the spoiler as you do until you reach the other side and tape ends.	<b>STEP 5:</b> Press down on the spoiler firmly to make sure the tape sticks. You can use masking tape to apply pressure on the spoiler.

We recommend not driving the car for approx 4 hours after installation to let the tape properly stick to the boot.

Masking tape can be used to hold the spoiler down after fitment if the vehicle needs to be driven.








## BOOT SPOILER INSTALLATION GUIDE

Please inspect the boot spoiler prior to installation and report any issues.

Do a test fit on the vehicle before fitting the 3M Tape to make sure the fit is correct and to find the perfect location for the spoiler. It's very important to clean the boot surface with alcohol rub or mentholated spirits to remove any oil, wax and dirt from the surface.

**Attach/ stick the supplied 3M tape to the back / underside of the boot spoiler, using all the tape to cover all areas of contact with the car boot. Once tape is fitted please follow the spoiler installation steps below:**

				
<b>STEP 1:</b> Clean boot / trunk lid with alcohol rub or mentholated spirits. Making sure there is no dust, wax or dirt on the surface.	<b>STEP 2:</b> Peel of the pre-fixed backing tape a bit at one side as shown in picture above.	<b>STEP 3:</b> Stick the spoiler from one side of the boot to the other; follow the curvature of the boot / trunk lid to the other side.	<b>STEP 4:</b> Slowly peel off the tape, pressing down on the spoiler as you do until you reach the other side and tape ends.	<b>STEP 5:</b> Press down on the spoiler firmly to make sure the tape sticks. You can use masking tape to apply pressure on the spoiler.

We recommend not driving the car for approx 4 hours after installation to let the tape properly stick to the boot.

Masking tape can be used to hold the spoiler down after fitment if the vehicle needs to be driven.